

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
<b>CANON 佳能</b>			
CANON	PC-25/PC10/PC14/PC20	UPPER ROLLER	FB2-5936-060
CANON	NP-155/150/150Z	UPPER ROLLER	FA2-9036-000
CANON	NP-270/250/350	UPPER ROLLER	FA2-8286-000
CANON	NP-1215/1218/1318/2010/6116/6318	UPPER ROLLER	FA5-1916-000
	NP-1015/1510/1520/1530/1550		FA5-1916-050
	C7039/7147/7318,GR1450		
CANON	NP-2020/2120/3020/LC3030/3100/3120	UPPER ROLLER	FA6-5361-000
	NP-6220/6221/C150/180/1820/300		
CANON	NP-1010/1020/6010,PC6/7/8/11/C100	UPPER ROLLER	FB1-9212-000
CANON	NP-3000/3025/3225/3525/3725	UPPER ROLLER	FA3-8866-000
CANON	NP-3030/3050	UPPER ROLLER	FA6-3024-040
	NP-3825/3325		FA6-3024-000
CANON	NP-2015/2017/2215	UPPER ROLLER	FA4-4662-020
CANON	NP-4015/4050/4080/4335/4835	UPPER ROLLER	FA5-2956-030
	NP-6241		FB1-5948-000
CANON	NP-400/500	UPPER ROLLER	FA2-1911-070
CANON	NP-6025/6028/6030/6031/6035	UPPER ROLLER	FB1-7956-000
	NP-6220/6230/6330		FB3-6936-000
CANON	GP-225/285/315/335/405/30F/55F	UPPER ROLLER	FB5-0289-020
	IR-330/400		FB6-3405-000
CANON*	NP-6045/6050/6250/6251/6350	UPPER ROLLER	FB2-7200-000
	NP-6445/6450/6545		
	NP-6550/6551/6750/7500		
	GP-555/605		
	IR-550/560/600		
CANON*	NP-6060/6062	UPPER ROLLER	FA6-7987-000
CANON*	NP-4035/4040/4540	UPPER ROLLER	FA5-7730-000
	NP-5020/5060		
	NP-6150/6650		
CANON	NP-6317/6320/6321	UPPER ROLLER	FC2-9961-000
CANON	NP-7160/7161/7163/7210/7214	UPPER ROLLER	N/A
CANON*	NP-6080/6085/6285/6880	UPPER ROLLER	FG2-2180-000/FA5-3714-000
CANON*	NP-7050/7550	UPPER ROLLER	FA5-3714-000
	NP-8070/8530/8570/8580		FA5-7249-000
	NP-9030/9330/9800		FB1-9885-020
CANON	NP-9130	UPPER ROLLER	
CANON	IR-1600/1610F;IR-155/200	UPPER ROLLER	FB5-8132-000
	IR-2000/2010F		FB5-8144
CANON*	IR-5000/5000i/5020/5020i	UPPER ROLLER	
	IR-6000/6000i/6020/6020i		FB4-3639-000
	NP-6065/6260/6360/6560		FB4-3690-000
CANON*	IR-105/7086/7095/7105/7200/7285/8500	UPPER ROLLER	FB5-6930-000
CANON	IR-5055/5065/5075	UPPER ROLLER	FC6-3566-000
CANON	IR-5570/6570	UPPER ROLLER	

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
CANON*	IRC-3100/3170/3200/3220 COLOR	UPPER ROLLER	FB6-3405-000
	IRC-2620		
	IRC-4580 COLOR		FB6-3641-000
CANON*	CLC-1100,1130,1140,1150,1180,1200 COLOR	UPPER ROLLER	
	CLC-5000 COLOR		
CANON*	IRC-5800/5850/5870 COLOR	UPPER ROLLER	
	IRC-6700/6800/6850		
<b>RICOH</b> 理光			
RICOH	FT-5010/5050/5070/5740	UPPER ROLLER	AE011001
	FT-5520/5530/5540/5550/5560/5570/5580/5590		
	FT-6620/6750		
	DS320/LP4400		
RICOH	FT-4050/4060/4065/4085	UPPER ROLLER	AE011006
	FT-4410/4420/4430/4470/4480/4490/4495/4630/4730		
	FT-5010/5034		
RICOH	FT-3300/3350	UPPER ROLLER	AE011002
	FT-4227/4427/4460/4530/4727/4800/4820		
	FT-5233/5433/5733		
RICOH	FT2200/2260	UPPER ROLLER	AE011035
	FT4215/4220/4222/4415/4418/4421/4422/4520/4525		AE011007
RICOH	FT5030/5035/5535/5627/5632/5832	UPPER ROLLER	AE011027
RICOH	FT4022/4027/4522/4527	UPPER ROLLER	AE011024
RICOH	FT-4500/5500	UPPER ROLLER	AE011020
	FT-6350/6500/6645/6655/6665		
	FT-7500/7650/7660/7670/7700F/7950/7960/7970		AE011042
	SPIRIO-5000/7000		
RICOH	FT-5640/5740/5840	UPPER ROLLER	AE011045
RICOH	FT-3020/3050/3060	UPPER ROLLER	54479525
RICOH	FT-3320	UPPER ROLLER	AE011012
RICOH	FT-4015/4615/4618	UPPER ROLLER	A2984081
	FT-3013/3113/3213/3313		A2194081
	FT-3415/3513/3713		AE011033
RICOH	AF-1013/1013D/1013F A4	UPPER ROLLER	AE011061
	AF-120/1515		AE011086
RICOH	AF-150/180 B4	UPPER ROLLER	A250-4110
RICOH	AF-1015/1018/1018D/1113/1115	UPPER ROLLER	AE011065
	AF-2015/2018		AE011080
	MP-1500/1600		AE011105
RICOH	AF-1022/1027	UPPER ROLLER	AE011058
	AF-2022/2027/2032		
	AF-3025/3030		
	MP-2510/3010		
RICOH	AF-1035/1045	UPPER ROLLER	AE011071
	AF-2035/2045		AE011102
	AF-3035/3045		AE011064

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
RICOH	AF-1050/1085/1105	UPPER ROLLER	AE01-1049/1080
	AF-850/2090/2105		AE01-1056
RICOH	AF-1060/1075	UPPER ROLLER	AE01-1087
	AF-550/551		AE011044
	AF-650/700		AE01-1069
RICOH	AF-2060/2075/2051	UPPER ROLLER	AE01-1117
RICOH	AF-200	UPPER ROLLER	G0204170
RICOH	AF-250	UPPER ROLLER	A2244170
RICOH	AF-220	UPPER ROLLER	AE01-1048
	AF-270		A2244170
RICOH	AF-2200/2500	UPPER ROLLER	A224-4170
RICOH	AF-340/350/450	UPPER ROLLER	AE011041
RICOH	AF-400/401/500	UPPER ROLLER	AE011036
RICOH	MP-1100,1350,9000	UPPER ROLLER	
<b>TOSHIBA 东芝</b>			
TOSHIBA	BD-1210/1340/1350/1360/1370	UPPER ROLLER	4409824690
	BD-2810		HR1210/1350U
TOSHIBA	BD-1310	UPPER ROLLER	HR24TAU
	BD-3810/3910		
TOSHIBA	BD-1550	UPPER ROLLER	4409849370
	BD-1560/1568		HR1550U
TOSHIBA	BD-1650	UPPER ROLLER	4409848760
	BD-2030/2050/2540		HR2050UN
TOSHIBA	BD-2060/2068/2860/2868/2870/2878	UPPER ROLLER	HR2060U
	BD-3560/3570		4409890600
	DP-2460/2470		
TOSHIBA	BD-2500/2510/2550	UPPER ROLLER	4409848850
	BD-1710/2310		HR2510U
TOSHIBA	BD-3110	UPPER ROLLER	HR30TAU
TOSHIBA	BD-3220/3550/3850	UPPER ROLLER	HR4010U
	BD-4010		
TOSHIBA	BD-3210/3240	UPPER ROLLER	HR3240U
	BD-2532		
TOSHIBA	BD-3301	UPPER ROLLER	HR35TAU
	BD-4111/4122/4130		
TOSHIBA	BD-4511/4515	UPPER ROLLER	HR40TFU
	BD-3503/3701		
TOSHIBA	BD-4810/4910	UPPER ROLLER	HR35TFU
	BD-5120/5610		
TOSHIBA	BD-5511	UPPER ROLLER	HR40TIU
TOSHIBA	BD-7811/7812/7815/7816	UPPER ROLLER	HR40TEU
TOSHIBA	BD-7720	UPPER ROLLER	
TOSHIBA	BD-4550	UPPER ROLLER	4409-894590
TOSHIBA	BD-4560/4570	UPPER ROLLER	

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
TOSHIBA	BD-5540/5560	UPPER ROLLER	
	BD-6550/6560		
	BD-7550/7560/7650/7660		
	DP-4580/5580/5570/6570/8070		
	E-studio 55/65/80		
TOSHIBA	E-studio 163/205/206	UPPER ROLLER	6LE19935000/HR-1640-U
TOSHIBA	E-studio 230/260/280/282	UPPER ROLLER	6LA2784600
TOSHIBA	E-studio 16/160/161/166/168/169	UPPER ROLLER	41303609000
	E-studio 208/250/258		
	DP-1600/2000/2500/2503		
TOSHIBA	E-studio 288/358/458	UPPER ROLLER	
	E-studio 25/28/35/45		44299019000
	DP-2800/3500/4500		HR3500U
TOSHIBA	E-studio 350/352/450	UPPER ROLLER	6LA27552000
TOSHIBA	E-studio 520/550/558	UPPER ROLLER	6LA23092000
	E-studio 600/650/810		
	DP-5510/6510/8110		4402038420
TOSHIBA	E-255/355/455		
<b>MITA KyoceraKM 京瓷美达</b>			
MITA Kyocera	KM-1500/1550/158/150/1815/1820, FS-720/820/920,AD-158	UPPER ROLLER	5MMT876AX002 2BY20010
	** KM1510/1505/1810		** 2A193060 2A120011
**	Ecosy FS-1018/1020	**	2BY20010
MITA Kyocera	KM-1525/1530	UPPER ROLLER	2AV93071
	KM-2030,AD-159		2AV20100
MITA Kyocera	KM-1620/1635/1650	UPPER ROLLER	2C920050
	KM-2020/2035/2050/2550		2C920051
	AD-165/169		2HF25010
MITA Kyocera	KM-2530	UPPER ROLLER	2BK20012
	KM-3530/3531/4030		2BK20011
MITA Kyocera	KM-2540/2560	UPPER ROLLER	2H094160
	KM-3040/3060		
MITA Kyocera	KM-3035/4035/5035	UPPER ROLLER	2FG20050
	AD-259/309		
MITA Kyocera	KM-3040/3045/3050	**	2GR94280
MITA Kyocera	KM-4230/5230	**	2AC20370
MITA Kyocera	KM-6030/8030	UPPER ROLLER	
AURORA	AD-158,KM-1500	UPPER ROLLER	2BY20010
AURORA	AD-159,KM-1525/1530/2030	UPPER ROLLER	
AURORA	AD-165/169,KM-1620/2020	UPPER ROLLER	
AURORA	AD-259/309,KM-3035/4035/5035	UPPER ROLLER	
MITA	DC-3060	**	33893101

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
MITA	DC-3050/4050/4230/5230	UPPER ROLLER	2GR94270
	DC-6030/6040/7340/7350		2BC20530
MITA	DC-1060/1560/1860	UPPER ROLLER	34993201
	DC-2050/2060/2360/2560		
MITA	DC-1550/1556/1605/1656/1657/1685	UPPER ROLLER	65420090
	DC-1755/1855/1856		66020170
	DC-2155/2255/2285/2355/2556/2557/3055		66220150
	AC-6500		65420090
MITA	DC-2285/2055	UPPER ROLLER	65420090
	DC-1605/1656/1685		
MITA	DC-2555/2585	UPPER ROLLER	
	DC-3255/3285/3555/3755/3785		
	DC-4555/4585/4855/4885		
MITA	DC-211/213/2105	UPPER ROLLER	43326212
MITA*	DC-5090 重	UPPER ROLLER	
	DC-6230/6330/7530 重		
MITA	DC-24	UPPER ROLLER	
<b>MINOLTA 美能达</b>			
MINOLTA	EP-1050	UPPER ROLLER	1139-5562-01
	EP-1080/1081		1139-5562-02
MINOLTA	EP-2010/2051/2080	UPPER ROLLER	1012-5521-01
	EP-3000/3010		
MINOLTA	EP-3170/3190	UPPER ROLLER	1065-5851-01
	EP-4210/4211		
MINOLTA	EP-350Z	UPPER ROLLER	1028-1701-03
MINOLTA	EP-450/450Z/470/490	UPPER ROLLER	1033-1701-02
	EP-550/570		1046-1703-01
MINOLTA	EP-4230/4233/425Z/410/415/370	UPPER ROLLER	1054-1703-02
	EP-4300/4301		1053-1701-01
MINOLTA	EP-2050/3050/4000/4050/4320	UPPER ROLLER	1052-1701-03
	EP-5320/5325/5400/5401/5420/5425		1076-5802-01
MINOLTA	EP-1052/1054/1083/1084/1085	UPPER ROLLER	1151-5521-02
	EP-2010/2030		1174-5521-01
	DI-181		1152-5521-03
MINOLTA	EP-5000	UPPER ROLLER	1156-5802-01
MINOLTA	EP-6000/6001/6002/6003/8015	UPPER ROLLER	1075-5768-01
	DI-520/620		
MINOLTA	EP-2120/2100/3150	UPPER ROLLER	1050-1701-04
MINOLTA	EP-8010/9760	UPPER ROLLER	1074-5714-02
MINOLTA	EP-850/860/870/8600/8601/8602/8603/8605	UPPER ROLLER	1031-1708-01
	EP-9600/9760/9765		1031-1708-02
MINOLTA	Di-152/183F,K7118/7115	UPPER ROLLER	4021-5701-02
MINOLTA	Di-106/162/163/1611/1811/2011	UPPER ROLLER	N/A
	Bizhub-162/210		
MINOLTA	Di-30/33	UPPER ROLLER	

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
MINOLTA	Di-200/251	UPPER ROLLER	4012-5730-03
	Di-351/351F		4011-5730-03
MINOLTA	Di-2010/2510,K-200/250/350	UPPER ROLLER	
	Di-3010/3510/3510F		4030-5701-03
	Bizhub-200/250/350		4688-3032-01
MINOLTA	Di-250	UPPER ROLLER	1164-5704-01
	Di-350/350f		1165-5706-01
MINOLTA	Bizhub-420/500	UPPER ROLLER	50GA-53030
MINOLTA	Di-450/460/470	UPPER ROLLER	4002-5701-01
	Di-550/552		4344-5003-01
MINOLTA	Di-451,K7145		
MINOLTA	Bizhub-600 (美国) 铝 同DI-600尺寸一样,重量轻一点	UPPER ROLLER	
MINOLTA	Bizhub-600/750 (日本) 铁管	UPPER ROLLER	
	DI-551/650		4024-2002-01
MINOLTA	DI-750/850	UPPER ROLLER	4014-3015-01
BIZHUB	BHC-500/600 棕 color	UPPER ROLLER	
	BHC-5001/5500/8050 棕 color		
BIZHUB	BHC-250/350/450 红 color	UPPER ROLLER	
<b>KONICA 柯尼卡</b>			
KONICA	K-1015	UPPER ROLLER	25HA53081
	K-1212		
KONICA	K-115z/1018/1020/1515/1590/2020	UPPER ROLLER	508053150
KONICA	K-3035/3135/3130/3031	UPPER ROLLER	540053010
	K-2028/2125		
KONICA	K-1120/1216/1218	UPPER ROLLER	26AA53050
	K-2120/2223		26AA53053
KONICA	K-3032/3290/3320/3532	UPPER ROLLER	
KONICA	K-1012/1290/1512	UPPER ROLLER	490053050
KONICA	K-2230/2330	UPPER ROLLER	40AA53031
	K-3231/3331		
KONICA	K-3240/3340	UPPER ROLLER	40AA53031
KONICA	K-4045/4145/4155/4345	UPPER ROLLER	544053010
KONICA	K-7020/7022/7025/7030/7222/7228/7235	UPPER ROLLER	26NA53030
KONICA	K-7216/7516/7521	UPPER ROLLER	
KONICA	K-7115/7118	UPPER ROLLER	65022820
KONICA	K-7035/7130/7135/7145	UPPER ROLLER	40LA-53030
	Di-451		26TA-53030
KONICA	K-7033/7040/7045/7140	UPPER ROLLER	55GA53031
KONICA	K-7050/7055/7060/7065/7150	UPPER ROLLER	25SA53070
KONICA	K-7155/7165/7255/7272	UPPER ROLLER	56AE53052
KONICA	K-7075/7085	UPPER ROLLER	55VA53041
KONICA	K-250/350	UPPER ROLLER	
KONICA	K-2510/3510	UPPER ROLLER	
	Bizhub-250		

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
<b>SHARP 夏普</b>			
SHARP	Z-50/52/55/57/70/72/75/77/85 Z-2010/6000	UPPER ROLLER	NROLT0518FCZZ
SHARP	Z-60/7100/7200	UPPER ROLLER	NROLT0440FCZ1
SHARP	SF-7700/7750/7800/7850	UPPER ROLLER	NROLT0549FCZZ
SHARP	SF-7300/7320/7350/7370	UPPER ROLLER	NROLT0593FCZZ
SHARP	SF-2022/2022N/2025/2026/2027/2027N/2030/2040/2540 SF-7900/8300/8350/8400/8530 SF-1025	UPPER ROLLER	NROLT0719FCZZ NROLT0913FCZ1 NROLT0935FCZZ
SHARP	SF-810/8100/8260	UPPER ROLLER	NROLT0506FCZZ
SHARP	SF-8200	UPPER ROLLER	NROLT0369FCZZ
SHARP	SF-2035/2040	UPPER ROLLER	NROLT0962FCZZ
SHARP	SD-2050/2052	UPPER ROLLER	NROLT1074FCZZ
SHARP	SD-2060/2260 SD-3062/3065	UPPER ROLLER	NROLT0971FCZZ
SHARP	SF-1014 SF-2014/2114/2214/2314/2414/2514	UPPER ROLLER	NROLT1031FCZZ
SHARP	SF-1016/1018/1020/1116/1118/1120 SF-2016/2018/2020/2116/2118/2120/2121/2216	UPPER ROLLER	NROLT1063FCZZ
SHARP	SD-2075/3075/3076	UPPER ROLLER	NROLT0778FCZZ
SHARP	AR-150/151/152/153/155/156/158/159 AR-120/120E/121/122 AR-1240,AL-1340/1451 AL- AL-1521/1530/1540/1551 AL-1631/1641/1651/1661 Z-810/820/835	UPPER ROLLER	NROLI0014QSZZ 6LA58628800 NROLM0086QSZZ NROLI1140FCZZ
SHARP	SF-8500/8570/8800/8870 AR-5040	UPPER ROLLER	NROLT0613FCZZ NROLT0582FCZZ
SHARP	AR-160/161/162/163/164 AL-1600/1610/1620/1621/1625/1640/1650/1670 AR-1818/2718/2818/3818 AR-200/201/205/206/207/2005/2005E AR-5316	UPPER ROLLER	NROLI0030QSZZ NROLI0030FCZZ
SHARP	AR-405/407 AR-501/505/507	UPPER ROLLER	
SHARP	ARM-230/250/251/260/265/280/285/286/287 ARM-33/335/336/406	UPPER ROLLER	NROLT1228FCZZ
SHARP	ARM-235/255/271/275 ARM-5127/5631	UPPER ROLLER	NROLM0086QSZZ NROLR0053QSZZ
SHARP	ARM-236/237/276/277	UPPER ROLLER	NROLM0098QSZZ
SHARP	ARM-340/350/355 ARM-420/450/455	UPPER ROLLER	NROLT1313FCZZ
SHARP	ARM-550N/620/700U	UPPER ROLLER	NROLT11452FCZ1
SHARP	ARM-256L/258 ARM-316L/318	UPPER ROLLER	
SHARP	ARM-650/800	UPPER ROLLER	ON4409894240

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
<b>XEROX</b>	<b>施乐</b>		
XEROX	V-228/230/250/258/283/288 X-2015/2017/2018/2021/2350 X-310/330/338	UPPER ROLLER	022P50261
XEROX	X-1025/1027/1035/1038/2970/3970 X-5026/5038/5825	UPPER ROLLER	022S63128 022S61500
XEROX	X-5016/5018/5021/5028/5034 X-5321/5328/5334/5624/5626 X-5818/5820/5828/5830	UPPER ROLLER	022K20701
XEROX	V-300/400/450/500/530 V-5340/5352	UPPER ROLLER	059K99640
XEROX	V-3300	UPPER ROLLER	
XEROX	DC-220/330	UPPER ROLLER	
XEROX	DC-1321/3321/3320 ABLE-1180/1220/1320/3180/3221	UPPER ROLLER	N/A
XEROX	DC-250/251 N32/N24/N40 DC-340/350/351/3201 DC-400/440	UPPER ROLLER	N/A
XEROX	DC-450/451 DC-550/551/5500 DC-600/606/706	UPPER ROLLER	N/A
XEROX	WC-315/320 WC-415/420/425 DC-5016	UPPER ROLLER	059K35580
XEROX	DC-103F	UPPER ROLLER	
XEROX	DP-3116	UPPER ROLLER	
XEROX	DP-3117	UPPER ROLLER	
XEROX	DC-235/285 DC-423/428	UPPER ROLLER	022E87691
XEROX	XD-100/102/103F/104/105F XC-810/820/830	UPPER ROLLER	NROLI1140FCZZ
XEROX	DC-123/128/133 DC-236/286/336	UPPER ROLLER	N/A
XEROX	XP-4010	UPPER ROLLER	22E11560
XEROX	XP-5/10	UPPER ROLLER	
XEROX	XP-15/20	UPPER ROLLER	
XEROX	DC-P8E/380/385/390	UPPER ROLLER	
XEROX	DP-202/305	UPPER ROLLER	
XEROX	DP-541, EPS-8900	UPPER ROLLER	
XEROX	DC-12/1250/1255 COLOR	UPPER ROLLER	
XEROX	DC-2060/8000 COLOR	UPPER ROLLER	
XEROX	DCC-5065/6550/7550, Docucolor-250 COLOR	UPPER ROLLER	
XEROX	DCC-250/350 COLOR	UPPER ROLLER	
XEROX	DCC-500 COLOR	UPPER ROLLER	

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
<b>PANASONIC 松下</b>			
PANASONIC	FP-1307/1510/1530/1570	UPPER ROLLER	FFPMA00163
PANASONIC	FP-1670/1680/1780/2080/2082	UPPER ROLLER	FFPMA0359
	FP-7117/7121		
PANASONIC	FP-2670/2680	UPPER ROLLER	FFPMA0419
	FP-3270/3230/3280/3370		
	FP-7127/7132/7133		
PANASONIC	FP-7113/7115/7713/7715	UPPER ROLLER	FFPMA5242
PANASONIC	FP-7718/7722/7818/7824	UPPER ROLLER	FFPMA0576
			FFPMA0574
PANASONIC	FP-7728/7735/7742/7745/7750/7850	UPPER ROLLER	FFPMA0566/77
PANASONIC	FP-350	UPPER ROLLER	
PANASONIC	DP-1510/1810/2010	UPPER ROLLER	DZLA000119
PANASONIC	DP-1515/1520/1820/1820E/2020	UPPER ROLLER	DZLA000361
	DP-8020/8016		
PANASONIC	DP-3000/3000E	UPPER ROLLER	DZLA000236
	DP-2000/2500		DZLA000213
PANASONIC	DP-2310/2330	UPPER ROLLER	DZLA000372
	DP-3010/3030		
PANASONIC	DP-2510/3510/3520/3530	UPPER ROLLER	DZLA000286
	DP-8035		
PANASONIC	DP-4510/4520/4530	UPPER ROLLER	DZLA000266
	DP-6010/6020/6030		
	DP-8045/8060		
PANASONIC	DP-315	UPPER ROLLER	
PANASONIC	KX-501/502/503CN/523/551/552/553 FAX	UPPER ROLLER	
	KX-753/758 FAX		
PANASONIC	KX-513CN/613CN FAX	UPPER ROLLER	

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
<b>LASER PRINTER: 激光打印机</b>			
HP	HP/LBP-5 COLOR	UPPER ROLLER	
HP	HP-98A	UPPER ROLLER	
HP	HP-2,3 LBP-SX	UPPER ROLLER	RA1-3968-000
HP	HP-2P,3P LBP-LX	UPPER ROLLER	RF1-2505-000
HP	HP-4V LBP-BX	UPPER ROLLER	RB1-1442-000
HP	HP-4+ LBP-EX+,EXII	UPPER ROLLER	RB1-3516-020
HP	HP-4 LBP-EX	UPPER ROLLER	RB1-2263-000
HP	HP-3SI,4SI LBP-NX	UPPER ROLLER	RB1-0323-000
HP	HP/LBP-ST A4	UPPER ROLLER	RA1-4850-000
HP	HP/LBP-KT B4	UPPER ROLLER	
HP	HP-5SI/5SIMX/LBP-WX	UPPER ROLLER	
HP	HP-8000	UPPER ROLLER	
HP	HP-8100/8150	UPPER ROLLER	RB2-3521-000
HP	HP-9000/9040	UPPER ROLLER	RB2-5948
RICOH	FAX-2500L/2600L/3000L3100L/3200L/3500L	UPPER ROLLER	H081-2100
RICOH	RICOH MV-310	UPPER ROLLER	H515-2110
RICOH	RICOH MV-715	UPPER ROLLER	AE01-1022
XEROX	XEROX XP-4010	UPPER ROLLER	22E11560
XEROX	XEROX XP-5/10	UPPER ROLLER	
XEROX	XEROX XP-15/20	UPPER ROLLER	
XEROX	XEROX XP-103F	UPPER ROLLER	
XEROX	XEROX DC-P8E/380/385/390	UPPER ROLLER	
XEROX	XEROX DP-3116	UPPER ROLLER	
XEROX	XEROX DP-3117	UPPER ROLLER	
XEROX	XEROX DP-202/305	UPPER ROLLER	
XEROX	XEROX DC-286	UPPER ROLLER	
XEROX	XEROX-3210	UPPER ROLLER	
IBM	IBM-4317	UPPER ROLLER	
EPSON	EPSON-2000	UPPER ROLLER	
EPSON	EPSON-2020	UPPER ROLLER	
EPSON	EPSON-5200,5700,5800,	UPPER ROLLER	
EPSON	EPSON-6100	UPPER ROLLER	
EPSON	EPSON-6200,MINOLTA1300 LJ-1800	UPPER ROLLER	
EPSON	EPSON-1220/2180 FOUNDER-6100 LJ-5500	UPPER ROLLER	

# UPPER FUSER ROLLER

# SENTON

TYPE	MODEL	DESCRIPTION	OEM #
LENOVO	LJ-1800	UPPER ROLLER	
LENOVO	LJ-2312P	UPPER ROLLER	
LENOVO	LJ-2500	UPPER ROLLER	
LENOVO	LJ-2000 BROTHER MF-2040/2030/2050/7420/7020/7010	UPPER ROLLER	
LENOVO	LJ-5500	UPPER ROLLER	
LENOVO	LJ-3100 BROTHER-2880	UPPER ROLLER	
LENOVO	LJ-8500 COLOR	UPPER ROLLER	
	SAMSUNG-1510/1610/1710/565P,RICOH 4216	UPPER ROLLER	
SAMSUNG	XEROX Phas3117/3130/3120/3121,WC PE16/SCX-WC PE16/SCX4016/4200/4321		JC66-00601A
SAMSUNG	SAMSUNG-5100	UPPER ROLLER	
SAMSUNG	SAMSUNG-1430	UPPER ROLLER	
SAMSUNG	SAMSUNG-5312/5350	UPPER ROLLER	
SAMSUNG	SAMSUNG-4500/1210/1250/1500/1520P/808/555P	UPPER ROLLER	
	XEROX-3110/3210		
LEXMARK	LEXMARK E-120	UPPER ROLLER	
LEXMARK	LEXMARK T-610	UPPER ROLLER	
LEXMARK	LEXMARK T-630, 640	UPPER ROLLER	
LEXMARK	LEXMARK E-310,320	UPPER ROLLER	
LEXMARK	LEXMARK E-230,232,240	UPPER ROLLER	

**WIDE-FORMAT UPPER ROLLER****SENTON**

TYPE	MODEL	DESCRIPTION	OEM #
<b>CANON 佳能</b>			
CANON	NP-A2Z	UPPER ROLLER	
CANON	GP-90W	UPPER ROLLER	
CANON	NP-A0	UPPER ROLLER	
<b>RICOH 理光</b>			
RICOH	FW-480		
RICOH	FW-2400		
RICOH	FT-300W	UPPER ROLLER	
RICOH	FW-780/870	UPPER ROLLER	
RICOH	FW-810,840, 850	UPPER ROLLER	
RICOH	FW-700/740/750/760	UPPER ROLLER	
RICOH	FW-940	UPPER ROLLER	
RICOH	FW-7030	UPPER ROLLER	
RICOH	FW-770	UPPER ROLLER	
<b>奇普</b>			
奇普	KIP-1030/1818/1880,1900,2000	UPPER ROLLER	
奇普	KIP-6000,7000	UPPER ROLLER	
奇普	KIP-8000,8260	UPPER ROLLER	
奇普	KIP-2900	UPPER ROLLER	
奇普	KIP-3000	UPPER ROLLER	
奇普	KIP-2720	UPPER ROLLER	
<b>MITA KyoceraKM 京瓷美达</b>			
MITA	DC A2	UPPER ROLLER	
MITA	DC A0	UPPER ROLLER	
MITA	DC 3020	UPPER ROLLER	
MITA	DC 630	UPPER ROLLER	
京瓷	DC-4850	UPPER ROLLER	
<b>XEROX 施乐</b>			
XEROX	DW-6030,6050	UPPER ROLLER	
XEROX	DW-3030	UPPER ROLLER	
XEROX	X-2030/2040	UPPER ROLLER	
<b>SEIKO 精工</b>			
精工SEIKO	LP-1010/1020	UPPER ROLLER	

**UPPER ROLLER FOR COLOR COPIER: 彩色复印机上下辊**

<b>TYPE</b>	<b>MODEL</b>	<b>DESCRIPTION</b>	<b>OEM #</b>
CANON	IRC-3100/3170/3200/3220 COLOR	UPPER ROLLER	FB6-3405-000
	IRC-2620	UPPER ROLLER	
	IRC-4580 COLOR	UPPER ROLLER	FB6-3641-000
CANON	CLC-1100,1130,1140,1150,1180,1200 COLOR	UPPER ROLLER	
	CLC-5000 COLOR	UPPER ROLLER	
CANON	IRC-5800/5850/5870 COLOR	UPPER ROLLER	
	IRC-6700/6800/6850	UPPER ROLLER	
BIZHUB	BHC-500/600 棕 color	UPPER ROLLER	
	BHC-5001/5500/8050 棕 color	UPPER ROLLER	
BIZHUB	BHC-250/350/450 红 color	UPPER ROLLER	
XEROX	DC-12/1250/1255 COLOR	UPPER ROLLER	
XEROX	DC-2060/8000 COLOR	UPPER ROLLER	
XEROX	DCC-5065/6550/7550,Docucolor-250 COLOR	UPPER ROLLER	
XEROX	DCC-250/350/240? COLOR	UPPER ROLLER	
XEROX	DCC-500 COLOR	UPPER ROLLER	